



**NOTES:**

1. TRIM TOP OF SEAL TO 1" ABOVE TOP OF RINGS. CASTING SHOULD NOT REST ON SEAL.
2. PLACE "MASTIC" ON TOP OF CONE SECTION AND BENEATH SEAL.
3. NOT TO BE USED WHEN THERE ARE NO RINGS OR MORE THAN 18" OF ADJUSTMENT RINGS.



**CITY OF  
CHANHASSEN**

I & I  
BARRIER

REVISED:10-16

FILE NAME: G:\ENG\SPECS\2109

ENGINEERING DEPARTMENT

PLATE NO.:

2109