



NOTES:

1. Wires shown away from pipe for clarity. Wire shall be installed on the bottom side of the pipe below the springline. The wire shall be fastened to the pipe with tape or plastic ties at 5' intervals.
2. The connections must be made with the gauge appropriate Copperhead Snakebite Locking Connectors or approved equal.

TRACE WIRE PLAN (SEWER)
Not to scale



**CITY OF
CHANHASSEN**

SANITARY SEWER SYSTEM
TRACER WIRE DETAIL

REVISED: 9-19

FILE NAME: G:\ENG\SPECS\5506

ENGINEERING DEPARTMENT

PLATE NO.:

5506